

TI-89 Titanium: Transfer programs between handhelds

Connect the calculators using the cable. Make sure that the plugs are firmly pushed in on both handhelds.

To Transfer a Program:

On the receiving calculator:

2nd Var-Link, F3, 2, Enter

The calculator is now ready to receive a program.



On the sending calculator:

2nd Var-Link

Find the program you wish to send in the list of programs.



F4

Places a check mark in front of the program you will be sending.



F3, 1, Enter

Engages the process for sending the program. Wait until the word **DONE** appears before removing the cables.